



○ 神田校舎 1～3号館 地下3階～地下1階 ○


● 地下3階 ●




● 地下2階 ●





● 地下1階 ●



神田校舎 1～3号館 1階～3階



教室	定員
101	180
102	168
103	56
104	96
105	108
106	90
107	90
201	132
202	132
203	72
204	132
205	132
206	72
207	72
208	72
209	72
301	415
302	511
303	570
304	33
305	30
306	60




パビリコニー-W.C.


消火栓	
避難器具	
避難	
A E D	

神田校舎 1～3号館 4階～15階


4階




10階




5階




11階



6階




12階




教室	定員
ゼミ室41	30
ゼミ室42	42
ゼミ室43	42
ゼミ室44	33
ゼミ室45	36
ゼミ室46	36


7階




13階




8階



14階



9階



15階



消火栓

避難器具

避難

AED