



神田校舎 7号館 1階～3階


1階



2階



3階




教室	定員
731	192




神田校舎 7号館 4階～6階


4階



5階



6階




教室	定員
751	60
752	24
753	26
761	30
762	30
763	30
764	30


消火栓	
避難器具	
避難	
A E D	

神田校舎 7号館 7階・8階

7階



8階



教室	定員
771	30
772	30
773	30
774	30
781	30
782	30
783	30
784	30

